

Using Adabas Vista Online Services

The Adabas Vista Online Services application is accessible from Adabas Online System (AOS), either the demo AOS version supplied with Adabas, or the full AOS version.

- Online Services Main Menu
 - Navigation
 - Using PF Keys
 - Help Information
-

Online Services Main Menu

To invoke Adabas Vista Online Services

- Either select Adabas Vista from the AOS main menu

Or:

log on to SYSAVI and enter the command MENU.

The Main Menu screen appears:

```

09:29:50  ***** A D A B A S  VISTA SERVICES 8.1.2  *****                2006-05-29
                                           - Main Menu -                          V1MAINM1

      Code      Service
      ----      -
      0          System Settings
      1          Maintenance
      2          Session Monitoring
      3          Special Services
      4          Avilook
      5          About Adabas Vista
      .          Exit
      ----      -
Code...: _

You can easily switch around the tools for Fastpath, Vista etc by use of the
PF Keys shown, or use the codes COR, AFP, AVI, AAF, ATM as commands - anytime.

Command ==>
Enter-PF1---PF2---PF3---PF4---PF5---PF6---PF7---PF8---PF9---PF10--PF11--PF12
      Help      Exit      COR    AFP      AAF    ATM      Vers

```

The following options are available:

Option	Description
System Settings	Maintain Adabas Vista configuration file setting.
Maintenance	Maintain Adabas Vista rules and client runtime controls.
Session Monitoring	Monitor the current session.
Special Services	Provide installation and applied ZAP information for the Adabas Vista components.
Avilook	File analysis tool.
About Adabas Vista	Display product information.

Navigation

You can access screens in two ways:

- sequentially by selecting a menu service and entering it in the Code field; or
- directly by typing a numerical command on the command line.

For example, entering the command 1 . 1 on the command line directly accesses the Maintain Generations screen within the Rule maintenance function without first accessing the Maintenance menu.

Function	Object	Command
System Settings	Menu	0
	LFILE 152 Maintenance	0.1
Maintenance	Menu	1
	Partitioned Files	1.1
	Translation Rules	1.2
	Client Runtime Controls	1.3
Session Monitoring	Menu	2
Special Services	Menu	3
	Local SYSAVI Services	3.1
AVILOOK	Menu	4
About Adabas Vista	Information	5

Using PF Keys

SYSAVI uses PF keys for various actions. Key functions are standard throughout the system, wherever possible. The PF keys that apply to each screen are indicated at the bottom of the screen.

The following keys apply throughout the system:

PF Key	Function	Description
PF1	Help	invoke the help specific to the current screen
PF3	Exit	quit and return to the previous screen

The following keys apply generally, depending on the type of action or function in use:

PF Key	Function	Description
PF4	Refr	from active screens, refresh the data
PF5	Upd.	from general maintenance screens, commit the update
PF7	Back	from list screens, return to the previous page
PF8	Next	from list screens, move to the next page
PF10	Add	from general maintenance screens, add an object
PF12	Menu	return immediately to the main menu

Help Information

To invoke Adabas Vista help information

- Press PF1.

The help screen that appears applies to the current screen and may comprise several pages. From each help screen, you can access lower level options or return to previous, higher levels.

An example of a help screen follows:

```

10:54:00      ***** A D A B A S   VISTA SERVICES 8.1.2 *****      2006-05-29
              -   Help for Maintain Generations   -                   Page 1 of 1 V11100H1

```

This screen lists all defined generations.

You may define multiple generations of Adabas Vista rules which allows you to implement different configurations in a controlled manner.

Adabas Vista at runtime always executes using the active generation.

The following options are available:

- 1 ADD - PF10 Add a new generation
- 2 DISPLAY - 'D' = Display information about a generation
- 3 MODIFY - 'M' = Modify information about a generation
- 4 PURGE - 'P' = Purge a generation and all its rules
- 5 COPY - 'C' = Copy a generation and all its rules
- 6 ACTIVATE - 'A' = Activate a generation
- 7 EXPAND - 'E' = Work with the change deltas for a generation
- 8 display gentab = Display generation record
- 9 BROWSE - 'B' = Browse the base rules for a generation (readonly)

Enter options 1 to 9 for Help about the individual functions, or,
 . '.' to End Help, '-' for Previous Pages

In the above example, you can navigate by entering

-	to move backwards and up a menu level
1 - 9	to move down a level to the function selected

If the help screen comprises multiple pages, you can enter

+	to move to the next page
-	to move to a previous page until page 1, then back up a level