

P2-Y

Determines a line control's end (target) position on the y-axis.

Applies to	Line control.
Data Type	I4
Default Value	0
Possible Values	0 - 9999